

TW-BS-01/916

Wireless (916) Base Sounder

TW-BSB-23R-01/916

Wireless (916) Base Sounder VAD Red LED

TW-BSB-23W-01/916

Wireless (916) Base Sounder VAD White LED

WARNINGS AND LIMITATIONS

Our devices use high quality electronic components and plastic materials that are highly resistant to environmental deterioration. However, after 10 years of continuous operation, it is advisable to replace the devices in order to minimize the risk of reduced performance caused by external factors. Ensure that this device is only used with compatible control panels. Detection systems must be checked, serviced and maintained on a regular basis to confirm correct operation. Smoke sensors may respond differently to various kinds of smoke particles, thus application advice should be sought for special risks. Sensors cannot respond correctly if barriers exist between them and the fire location and may be affected by special environmental conditions. Refer to and follow national codes of practice and other internationally recognized fire engineering standards. Appropriate risk assessment should be carried out initially to determine correct design criteria and updated periodically.

Use only in Taurus fire detection and alarm systems.

WARRANTY

All devices are supplied with the benefit of a limited 5 years warranty relating to faulty materials or manufacturing defects, effective from the production date indicated on each product. This warranty is invalidated by mechanical or electrical damage caused in the field by incorrect handling or usage. Product must be returned via your authorized supplier for repair or replacement together with full information on any problem identified. Full details on our warranty and product's returns policy can be obtained upon request.

The warranty does not cover the provided batteries.

TW-BS-01/916



SAI Global
Lic SMK41004
AS ISO 7240.25

Australian
Standard

TW-BSB-23R-01/916



SAI Global
Lic SMK41004
AS ISO 7240.23
AS ISO 7240.25

Australian
Standard

TW-BSB-23W-01/916



SAI Global
Lic SMK41004
AS ISO 7240.23
AS ISO 7240.25


Australian
Standard

GENERAL DESCRIPTION

TW-BB-01/916, **TW-BB-23R-01/916** and **TW-BB-23W-01/916** base sounders are audio and audio-visual signalling devices used to alert people in the event of a fire.

These base sounders are designed to host Taurus series detectors, but they can operate autonomously if associated with a suitable cover plate.

TW-BB-01/916, **TW-BB-23R-01/916** and **TW-BB-23W-01/916** are battery powered and they don't need any system cabling installation.



Picture 1

DEPLOYMENT PROCEDURE



The general applicable procedure for the deployment of these products is the following:

- 1) Select a location for the base sounder. See **LOCATION SELECTION**.
- 2) Unbox the base sounder product from its packaging.
- 3) Detach the battery cover from the base sounder. See **BATTERY COVER**.
- 4) Detach the wall installation plate from the device. See **WALL INSTALLATION PLATE**.
- 5) Power up the base sounder. See **POWERING UP - FIRST TIME USE / POWERING UP - RECOVERY**.
- 6) Link the base sounder to the system. See **LINKING - WAKE-UP / LINKING - ONE-BY-ONE**.
- 7) Set the output acoustic's tone. See **SOUNDER OUTPUT'S CONFIGURATION**.
- 8) Set the output acoustic's volume. See **SOUNDER OUTPUT'S CONFIGURATION**.
- 9) Set the output visual signal's power (applicable only to **TW-BSB-23R-01/916** and **TW-BSB-23W-01/916**). See **SOUNDER OUTPUT'S CONFIGURATION**.
- 10) Drill out the required fixing holes on the wall installation plate. See **WALL INSTALLATION PLATE**.
- 11) Fix the wall plate. See **WALL INSTALLATION PLATE**.
- 12) Install the base sounder to the wall plate. See **WALL INSTALLATION PLATE**.
- 13) Fix the base sounder to the wall plate. See **FIXING THE BASE SOUNDER**.
- 14) Reinstall the battery cover. See **BATTERY COVER**.
- 15) Install the host detector. See **HOST DETECTOR / PLASTIC COVER INSTALLATION**.
- 16) Install the cover plate if the base sounder operates as standalone. See **HOST DETECTOR / PLASTIC COVER INSTALLATION**.
- 17) Secure the detector / cover plate with the safety anti-tamper screw. See **HOST DETECTOR / PLASTIC COVER INSTALLATION**.
- 18) Test the base sounder. See **TESTING**.

LOCATION SELECTION

Select a location for the base sounder that conforms to your local applicable safety standards and that is in a good position for sending / receiving wireless signals to / from the father **TW-MTI-01/916**, **TW-MEC-01/916** or **TW-ME-01/916** network device.




It is advisable to use the TW-SKT-01/916 survey kit to locate a good wireless installation location.

Mount the base sounder as far as possible from metal objects, metal doors, metal window openings, etc. as well as cable conductors, cables (especially from computers), otherwise the operating distance may greatly drop.


The base sounder must NOT be installed near electronic devices and computer equipment that can interfere with its wireless communication quality.

BATTERY COVER

To install the battery cover, insert its two hooks into the device's recesses as indicated in the picture below; then block it by pressing down the opposite side. To detach the battery cover, pull the tab highlighted in the following picture.



Picture 2



Picture 3

Use the little screw to fix the battery cover

Optional battery cover screw: to be used with base sounder lid cover only (not required with detector fitted)




Every time the cover is removed, the tamper switch is released, causing a tamper attempt message to be sent to the control panel.

Always install the battery cover, since it is a vital part of the anti-tampering feature.

Make sure the battery cover is safely fixed, blocked and closed.

WALL INSTALLATION PLATE

To detach / reinstall the wall plate to the base sounder refer to the following picture:




Picture 4



Make sure that the sound diffuser cone printed on the wall plate corresponds to the acoustic alarm signal outlet of the base sounder.

Drill templates on the wall plate are highlighted in the following picture:



Picture 5

LED INDICATOR STATUS MESSAGES

The LED indicator's messages are used only during installation and servicing. LED indicator is inactive when the battery cover is in place for saving up battery charge (and due to the fact that normally the LED is hidden by the detector or the cover plate).

| Device status | LEDs indication |
|------------------------------|--|
| Power up (DIP on "ON") | Blinks red 4 times |
| Power up (DIP opposite "ON") | Blinks green 4 times |
| Entering wake-up mode | Blinks alternatively green / red 4 times |
| Link success (one-by-one) | Blinks green 4 times, then the same pattern again |
| Link failure (one-by-one) | Enters wake-up mode and signals "Entering wake-up mode" following this failure |
| Link success (wake-up) | Blinks green 4 times, then same pattern again |
| Link failure (wake-up) | Blinks green 4 times, then blinks red on once, then blinks alternatively green / red 4 times |
| Normal condition | LED off (can be programmed so as to blink green every wireless communication) |
| Alarm activation | Blinks red every 2 seconds |
| Battery fault | LED off (can be programmed so as to blink amber every 5 seconds) |
| Tamper fault | LED off |
| Replaced | Blinks amber 2 times |

Table 1



With the battery cover installed, the LED indicator remains inactive.

POWERING UP AND LINKING - PRELIMINARY NOTES

TW-BS-01/916, **TW-BSB-23W-01/916** and **TW-BSB-23R-01/916** need to be powered up with the supplied batteries.

Linking is the operation through which these devices are "wirelessly connected" to a **TW-MTI-01/916**, **TW-MEC-01/916** or **TW-ME-01/916** Taurus network device.

POWERING UP - FIRST TIME USE

Use this procedure the first time you power up a **TW-BS-01/916**, **TW-BSB-23W-01/916** or **TW-BSB-23R-01/916**.

- 1) Make sure the Link / program switch is set on "ON".
- 2) Insert the two supplied batteries into their device's lodgments.

Ensure that the batteries are installed properly, with their polarities matching the indications on the device.

POWERING UP - DEVICE LINKED TO THE SYSTEM

Use this procedure when a **TW-BS-01/916**, **TW-BSB-23W-01/916** or **TW-BSB-23R-01/916** is successfully linked to its Taurus system and you have to extract one or both batteries (e.g. batteries substitution).

- 1) Reinsert the battery or both batteries into their lodgments.

Do not touch the Link / program switch.

If performing a batteries substitution, use two brand new batteries and substitute both of them.

Ensure that the batteries are installed properly, with their polarities matching the indications on the device.

POWERING UP - RECOVERY

Use this procedure when you fail to link successfully a **TW-BS-01/916**, **TW-BSB-23W-01/916** or **TW-BSB-23R-01/916** or you want to link it again.

- 1) Move alternatively the Link / program switch 5 times.
- 2) Set the Link / program switch on "ON".
- 3) Insert the two supplied batteries into their device's lodgments.

Ensure that the batteries are installed properly, with their polarities matching the indications on the device.

LINKING - WAKE-UP

"Wake-up" linking consists in associating one or more child devices to the Taurus system altogether in a single operation.

Wake-up is performed either through the **TauREX** software or the **TW-MTI-01/916 / TW-MEC-01/916** keyboard-screen interface; it CANNOT be done through **TW-ME-01/916** devices.

- 1) Create the "virtual model" of the base sounder device either on **TauREX** or on the **TW-MTI-01/916 / TW-MEC-01/916**.
- 2) Power-up the base sounder (either "first time use" or "recovery").
- 3) Set the Link / program switch OPPOSITE to "ON".
- 4) Trigger the wake-up procedure either from **TauREX** or from the **TW-MTI-01/916 / TW-MEC-01/916**.
- 5) Wait the end of the "wake-up" linking procedure.
- 6) Check on **TauREX** or from **TW-MTI-01/916 / TW-MEC-01/916** for linking success.
Consult their user manual.

LINKING - ONE-BY-ONE


"One-by-one" linking consists in associating one child device at a time to the Taurus system.

This operation is performed either through the **TauREX** software or the **TW-MTI-01/916 / TW-MEC-01/916** keyboard-screen interface; it CANNOT be done through **TW-ME-01/916** devices.

- 1) Create the "virtual model" of the child device either on **TauREX** or on the **TW-MTI-01/916 / TW-MEC-01/916**.
- 2) Trigger the linking procedure either from **TauREX** or from the **TW-MTI-01/916 / TW-MEC-01/916**.
- 3) Power-up the child device (either "first time use" or "recovery").
- 4) Set the child device's Link / program switch OPPOSITE to "ON".
- 5) Wait the end of the "one-by-one" linking procedure.
- 6) Check on **TauREX** or from **TW-MTI-01/916 / TW-MEC-01/916** for linking success.
Consult their user manual.

SOUNDER OUTPUT'S CONFIGURATION

To configure the acoustic and visual output you must set the DIP switch component placed inside the sounder's base. Switches' layout and function is illustrated below:



Picture 6

| Switch number | Function |
|---------------|--------------------------------|
| 1 | Acoustic output tone setting |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
| 6 | Acoustic output volume setting |
| 7 | |
| 8 | Visual output power setting |

Table 2

1) Orientate the DIP component in front of you so as to see it straight; "below" corresponds to "0", "up" corresponds to "1".

To change the switches use the tip of a little screwdriver.

- 2) Select the required output tone; switches combinations and the corresponding tones are found on table 5 for the main tone set and on table 6 for the alternative tone set.
- 3) Select the required output volume; switches combinations and the corresponding volume levels are found on table 3.
- 4) Select the visual emission's power; switch settings and the corresponding power levels are found on table 4 (applies only to **TW-BSB-23R-01/916** and **TW-BSB-23W-01/916**).

| Acoustic volume level | Switches configuration |
|-----------------------|------------------------|
| High | 11 |
| Medium-High | 01 |
| Medium-Low | 10 |
| Low | 00 |

Table 3

| Visual emission power level | Switch configuration |
|-----------------------------|----------------------|
| High | 1 |
| Low | 0 |

Table 4

| Tone number | Main tone designation | Main tone pattern description | DIP switches |
|-------------|--------------------------------------|---|--------------|
| 0 | Silent | No sound | 11111 |
| 1 | Warble Tone | 800Hz for 500ms, then 1000Hz for 500ms | 11101 |
| 2 | Continuous tone | 970Hz continuous tone | 01011 |
| 3 | Slow Whoop (Dutch) | 500-1200Hz for 3500ms, then off for 500ms | 10101 |
| 4 | German DIN tone | 1200-500Hz swept every 1000ms (1Hz) | 00111 |
| 5 | Alternate HF slow sweep | 2350-2900Hz swept every 333ms (3Hz) | 10010 |
| 6 | Alternative warble | 800Hz for 250ms, then 960Hz for 250ms | 11110 |
| 7 | Alternative warble | 500Hz for 250ms, then 600Hz for 250ms | 11100 |
| 8 | Analogue sweep tone | 500-600Hz swept every 500ms (2Hz) | 10100 |
| 9 | Australian Alert (intermittent tone) | 970Hz for 625ms, then OFF for 625ms | 10001 |
| 10 | Australian Evac (slow whoop) | 500-1200Hz sweep for 3750ms, then OFF for 250ms | 10110 |
| 11 | FP1063.1-Telecom | 800Hz for 250ms, then 970Hz for 250ms | 00001 |
| 12 | French tone AFNOR | 554Hz for 100ms, then 440Hz for 400ms | 00101 |
| 13 | HF Back up interrupted tone | 2800Hz for 1s, then OFF for 1s | 11011 |
| 14 | HF Back up interrupted tone - fast | 2800Hz for 150ms, then OFF for 150ms | 11001 |
| 15 | HF Continuous | 2800Hz continuous | 01001 |
| 16 | Interrupted tone | 800Hz for 500ms, then OFF for 500ms | 01111 |
| 17 | Interrupted tone medium | 1000Hz for 250ms, then OFF for 250ms | 01101 |
| 18 | ISO 8201 LF BS5839 Pt 1 1988 | 970Hz for 500ms, then OFF for 500ms | 01110 |
| 19 | ISO 8201 HF | 2850Hz for 500ms, then OFF for 500ms | 01100 |
| 20 | LF Back up Alarm | 800Hz for 150ms, then OFF for 150ms | 11010 |
| 21 | LF Buzz | 800-950Hz swept every 9ms | 01010 |
| 22 | LF Continuous tone BS5839 | 800Hz continuous | 11000 |
| 23 | Siren 2 way ramp (long) | 500-1200Hz rising for 3000ms, then falling for 3000ms | 00000 |
| 24 | Siren 2 way ramp (short) | 500-1200Hz rising for 250ms, then falling for 250ms | 00010 |
| 25 | Swedish all clear signal | 660Hz continuous | 00100 |
| 26 | Swedish Fire signal | 660Hz for 150ms, then OFF for 150ms | 00110 |
| 27 | Sweep tone (1 Hz) | 800-900Hz swept every 1000ms | 10111 |
| 28 | Sweep tone (3 Hz) | 800-970Hz swept every 333ms (3Hz) | 10011 |
| 29 | Sweep tone (9 Hz) | 800-970Hz swept every 111ms (9Hz) | 01000 |
| 30 | US Temporal Pattern HF | (2900Hz for 500ms ON, 500ms OFF) x3, then 1500ms OFF | 00011 |
| 31 | LF Sweep (Cranford tone) | 800-1000Hz swept every 500ms (2Hz) | 10000 |


Table 5

| Tone number | Alternative tone pattern description | DIP switches |
|-------------|---|--------------|
| 0 | 970Hz continuous | 11111 |
| 1 | 800Hz continuous | 11101 |
| 2 | 1000Hz continuous tone | 01011 |
| 3 | 500-1200Hz for 3500ms, then off for 500ms | 10101 |
| 4 | 800Hz continuous | 00111 |
| 5 | 2400Hz continuous | 10010 |
| 6 | 800Hz continuous | 11110 |
| 7 | 500Hz continuous | 11100 |
| 8 | 500Hz continuous | 10100 |
| 9 | 2400Hz continuous | 10001 |
| 10 | 500-1200Hz sweep for 3750ms, then OFF for 250ms | 10110 |
| 11 | 500-1200Hz rising for 250ms, then falling for 250ms | 00001 |
| 12 | 800Hz continuous | 00101 |
| 13 | 2800Hz continuous | 11011 |
| 14 | 800Hz continuous | 11001 |
| 15 | 2800Hz continuous | 01001 |
| 16 | 800Hz continuous | 01111 |
| 17 | 800Hz continuous | 01101 |
| 18 | 970Hz for 500ms, then OFF for 500ms | 01110 |
| 19 | 2850Hz for 500ms, then OFF for 500ms | 01100 |
| 20 | 800Hz continuous | 11010 |
| 21 | 800Hz continuous | 01010 |
| 22 | 800Hz continuous | 11000 |
| 23 | 800Hz continuous | 00000 |
| 24 | 800Hz continuous | 00010 |
| 25 | 660Hz continuous | 00100 |
| 26 | 660Hz for 150ms, then OFF for 150ms | 00110 |
| 27 | 800Hz continuous | 10111 |
| 28 | 800Hz continuous | 10011 |
| 29 | 800Hz continuous | 01000 |
| 30 | 2900Hz continuous | 00011 |
| 31 | 800Hz continuous | 10000 |

Table 6

FIXING THE BASE SOUNDER

To fix the base sounder to the wall plate insert and fix the supplied screws in the holes highlighted in the following picture:



Picture 7

HOST DETECTOR / PLASTIC COVER INSTALLATION

If a detector is hosted, follow the setup instructions on its installation manual.



Make sure the detector's OWN battery cover is installed to avoid tamper detection events.

If a detector is not hosted, always use a Taurus cover plate to close and protect the inside of the base sounder.

The cover plate is not supplied together with the product.

For placing the detector / plastic cover refer to the following picture:



Picture 8



Always install the safety blocking screw.

BATTERY FAULTS AND BATTERY SUBSTITUTION PROCEDURE

When one or both batteries are low in charge, a specific fault message is routed to the control panel. If such event occurs:

- 1) Remove the safety screw.
- 2) Remove the detector / plastic cover from its base.
- 3) Remove the batteries cover.
- 4) Extract both batteries.
- 5) Insert both new batteries into their holders, oriented as per polarity marks. See **POWERING UP - DEVICE LINKED TO THE SYSTEM**.
- 6) Check, through the indicator LED, that the device is in normal condition.
- 7) Reinstall the batteries cover.
- 8) Reinstall the detector / plastic cover.
- 9) Reinstall the safety screw.

TESTING

Test the base sounders as follows:

- 1) Trigger an alarm condition (call point activation, approved detector aerosol / heat testers).
- 2) Check the acoustic alarm output of the base sounder.
- 3) Check the visual alarm output of the base sounder (**TW-BSB-23R-01/916** / **TW-BSB-23W-01/916** only).
- 4) Remove the alarm condition.
- 5) Check that a normal condition persists (i.e. test smoke can stagnate in a detector's smoke chamber causing the alarm to be triggered again).



When a low battery condition is indicated, both batteries must be changed altogether.

Batteries must be brand new.

Do not touch the Link / program switch.

Ensure that the batteries are installed properly, with their polarities matching the indications on the device.



Local safety standards may require you to test these devices on a regular basis.



TECHNICAL SPECIFICATIONS *

| Specification | Value |
|---|-----------------------|
| Communication range with TW-MTI-01/916 , TW-MEC-01/916 or TW-ME-01/916 network devices | 200 m (in open space) |
| Wireless frequency band | 916 MHz |
| Number of wireless channels | 66 |
| Radiated power | 14 dBm (25 mW) |
| Operating temperature range | -10 °C to 55 °C |
| Maximum humidity (non condensing) | 95% RH |
| Certified IP rating (AS ISO 7240) | IP 21C |
| Environmental application | Indoor use only |

Table 7

* See TDS-TWBSX technical specification document for further technical data.

BATTERY SPECIFICATIONS

| Specification | Value |
|---------------------------------------|-----------------------|
| Batteries type * | CR123A (3 V, 1.25 Ah) |
| TW-BS-01/916 | 5 + 1/2 years |
| TW-BSB-23W-01/916 | 4 + 1/2 years |
| TW-BSB-23R-01/916 | 4 + 1/2 years |
| Low battery threshold value (nominal) | 2.850 V |

Table 8

* When a low battery condition is indicated, both batteries must be changed altogether.

** Batteries lifespan depends by environmental conditions, default monitor settings and link quality.

ACOUSTIC SPECIFICATIONS

| Specification | Value |
|---|-------------------|
| Number of tones | 32 |
| Tone 1 (warble tone) typical sound output | 88 dB(A) |
| Tone 2 (continuous tone) typical sound output | 91 dB(A) |
| Tone 3 (Dutch slow whoop tone) typical sound output | 91 dB(A) |
| Tone 4 (German DIN tone) typical sound output | 89 dB(A) |
| Acoustic output frequency range | 440 Hz to 2900 Hz |

Table 9

ACOUSTIC PERFORMANCE

| Horizontal plane L _{AFmax} @ 1m (dBA) | | | | | | | |
|--|-------|------|------|------|------|------|---------|
| Tone Number | Angle | | | | | | Average |
| | 15° | 45° | 75° | 105° | 135° | 165° | |
| Tone 1 | 81.1 | 81.3 | 84.6 | 85.0 | 80.4 | 82.7 | 82.9 |
| Tone 2 | 77.0 | 84.3 | 77.7 | 89.2 | 88.3 | 86.6 | 85.9 |
| Tone 3 | 83.2 | 84.9 | 88.5 | 88.7 | 89.5 | 87.7 | 87.6 |
| Tone 4 | 82.3 | 84.2 | 87.0 | 87.5 | 86.8 | 85.2 | 85.8 |

Table 10


| Vertical plane L _{AFmax} @ 1m (dBA) | | | | | | | |
|--|-------|------|------|------|------|------|---------|
| Tone Number | Angle | | | | | | Average |
| | 15° | 45° | 75° | 105° | 135° | 165° | |
| Tone 1 | 84.0 | 89.0 | 84.4 | 91.6 | 87.2 | 88.0 | 88.2 |
| Tone 2 | 87.2 | 86.8 | 76.7 | 96.9 | 90.0 | 89.1 | 91.1 |
| Tone 3 | 86.7 | 88.1 | 85.4 | 95.1 | 90.4 | 90.5 | 90.6 |
| Tone 4 | 85.4 | 87.0 | 84.9 | 92.9 | 89.0 | 88.9 | 88.9 |

Table 11

VAD SPECIFICATIONS

| Specification | Value | Notes |
|-----------------------------------|---|--|
| Flash frequency | 0.5 Hz | |
| WHITE flash / HIGH power coverage | Ceiling mounted, 3 m height, 15 m coverage diameter, 10.61 m x 10.61 m (112.5 m ²) square coverage. Ceiling mounted (AS ISO 7240.23 open "O" class), 4.6 m height, 15 m coverage diameter, 10.61 m x 10.61 m (112.5 m ²) square coverage | C3-15 (AS ISO 7240.23) O4.6-15 (AS ISO 7240.23) |
| RED flash / HIGH power coverage | Ceiling mounted, 3 m height, 10 m coverage diameter, 7.07 m x 7.07 m (50 m ²) square coverage | C3-10 (AS ISO 7240.23) |
| WHITE flash / LOW power coverage | Ceiling mounted, 3 m height, 10 m coverage diameter, 7.07 m x 7.07 m (50 m ²) square coverage | C3-10 (AS ISO 7240.23) |
| RED flash / LOW power coverage | Ceiling mounted (AS ISO 7240.23 open "O" class), 1.7 m height, 6 m coverage diameter, 4.24 m x 4.24 m (18 m ²) square coverage | O1.7-6 (AS ISO 7240.23) |

Table 12



Ceiling Mounted Device Demonstration

Re. Item TW-BSB-23R-01/916 and TW-BSB-23W-01/916 only